







Oszillograf über 200 kOhm  
an R46/C44 anschließen.  
5,5 MHz - Signal (FM an)  
S53/S40




Brummspannungen  
C15/C16 (+1) 28 V<sub>ss</sub>  
C18 (+2) 4,5 V<sub>ss</sub>




8 X/R10 7 V<sub>ss</sub> 15,625 Hz




9 X/R10 10 V<sub>ss</sub> 15,625 Hz



7 3,0 V<sub>ss</sub> 15,625 Hz



10 5,0 V<sub>ss</sub> 15,625 Hz



10 5,7 V<sub>ss</sub> 15,625 Hz

