




Naponi na biraču kanala

	K6	K5	K4	K3	K2	K1
VHF	12V	12V	12V	12V	12V	12V
UHF	12V	12V	12V	12V	12V	12V

