




<http://orlovac.eu/>



Shema kontaktnog sloga vrijedi za tipomatik-agregat


Tonski izlazni transformator

Vertikalni izlazni transformator




Bloking transformator

Točka označena crvenim nitro lakom.




Raspored priključaka ITL



Priključci tunera:

- | | |
|------------------------|-------------------------|
| A VHF - Antenski ulaz | B UHF - Antenski ulaz |
| 1 VHF - Oscillator | 1 UHF - MF izlaz |
| 2 VHF - MF izlaz | 2 UHF - Oscillator |
| 3 VHF - Miješanje | 3 U varicap |
| 4 VHF - UHF - MF ulaz | 4 ARP za max. pojačanje |
| 5 Napon za podešavanje | 5 Predpojačalo |
| 6 Korekcionni napon | |
| 7 Napon za prekapčanje | |
| 8 ARP | |
| 10 Predpojačalo | |

Naponi mjereni bez signala na praznom kanalu uz max. kontrast i min. svijetlo (min kontrast; max svijetlo)
Oscilogrami snimljeni uz signal 1mV, max. kontrast, a min. svijetlo



Pridržavamo si pravo izmjene